

Instructions for Syringe Driver Bags

Body of Bag

Cut 2 pieces (front & back)

5½ inches x 11½ inches

lining cut 2 pieces in lining material

Sides of Bag

Cut 2 pieces

3¾ inches x 11½ inches

lining cut 2 pieces in lining material

Bottom of Bag

Cut 1 piece

3¾ inches x 5½ inches

lining cut 1 pieces in lining material

Pieces needed:

Using suitable scrap fabrics. Fabric must be washable.

1. **Body of bag (front & Back)** - Cut 2 pieces - 5½ inches x 11½ inches
2. **Sides** – Cut 2 pieces - 3¾ inches x 11½ inches
3. **Bottom** – Cut 1 piece - 3¾ inches x 5½ inches
4. **Strap** – Shoulder strap to go across the body (see photograph) this can vary in length approx. 47 inches long x 3-4 wide.
 - a. The strap is very long and you may not have enough fabric to cut it in one piece, in which case please do join the fabric to produce a strap of the correct length.



Bag will be across body, different sizes, a longer strap can be tied to shorten it to suit different sizes of people.

Instructions:

Strap: Cut fabric 47 inches long x 3-4 wide. Press the fabric to the wrong side by $\frac{1}{4}$ inch on all edges of the strap. Fold the strap down the centre and press, making sure the long-folded edges meet neatly and that the short edges are tucked in. Using a $\frac{1}{4}$ inch seam allowance, stitch right around the strap.

Making the main bag

1. Cut out all the required pieces.
2. Seam allowance approx. $\frac{1}{4}$ inch
3. Join sides to body pieces.
4. Pin the bottom piece to the longer front & back at bottom and sew across to side seams.
5. Then pin the smaller side pieces to bottom and sew.
6. Turn your bag right side out.
7. Make lining bag in the same way but don't turn.
8. Place lining bag inside the outer bag and push into corners neatly, then turn both materials in at the top.
9. Place strap evenly into the gap at each side and sew strap in place.
10. To strengthen strap, sew at sides a few extra times.